



Chafer Instructions

- Set chafer on a flat, stable surface
- Fill the water pan with 2" of **hot** water
- Place the *fully cooked* food into the food pan(s) and place the food pan into the water pan.
- Cover the food with the chafer lid.
- Light the Sterno fuel cans and carefully place them inside the base tray (rolling lid chafers) or place inside the Sterno holders and then light (lift-off lid chafers). Sterno holders have an adjustable lid for changing your flame from low to high.

Tips

If your food is not hot when you load it into the food pan you will need to light the Sterno 30 minutes before serving time.

Each can of Sterno has an average of 2 hours of burn time. Check the flame often in windy conditions.

Check the water level often. *Do not* use the chafer with no water in the base, as this will scorch the pans and burn your food, and may result in replacement charges.

Always use either one full size pan or two half size pans over the water pan, or food will get soggy.

Chafers are for serving food only, **never** cook your food in the chafer pans provided with your rental.

Cleaning

All pieces must be fully cleaned before returning to the store. Items returned dirty will be subject to cleaning charges. Pans must be returned in the same condition they left the store in. All missing/damaged items will be subject to charges; please note all items provided with rental and return them together.