



Fog Machine Instructions *Chauvet Hurricane 1300*

Getting Started: Place the fog machine on a sturdy level surface out of the way, and keep all fabrics and heat sensitive items at least two feet from the machine. Keep the area in front of the nozzle clear of obstructions. Plug in the power cord to a grounded outlet, and plug the remote control into the manual controller input in the back of the machine. Fill the fluid reservoir with at least one pint of fog fluid, and make sure the intake hose for the pump is fully submerged as you close the reservoir.

Creating Fog: Turn the power switch to the ON position, and make certain the light illuminating the fluid tank lights up to indicate the machine is receiving power. The machine will take around 2-5 minutes to warm up before it will begin producing fog. Once small amounts of fog start drifting out of the nozzle at the front of the machine, it is ready for use. You can use the controller to set regular intervals for bursts of fog, or you can press and hold the manual button periodically to achieve your desired effect. Keep an eye on the fluid level indicator light, and refill the machine promptly when the fluid gets low. Running the pump with no fluid in the machine can damage the fog machine.

Cleanup and Return: Turn off the machine before unplugging it from the power source. Empty the fluid reservoir before returning packing it into its container. Make sure all cords and cables are returned with the machine, and return any unopened bottles of fog fluid to the store.

Caution: Vapor from this fluid may be irritating to some persons with allergic sensitivities. Do not expose at close range or high concentration to known asthmatics. Use in a well ventilated area.

322 Thain Road
Lewiston, Id 83501
(208)746-4246

222 North Main Street
Moscow, Id 83843
(208)883-4246